

## Level and Adjust (2) Foot Pads

---

**Adjust both (2) foot pads under front of platform to properly level Machine per illustration.**



**Platform must *NOT* touch floor after adjustment. Allow spacing for hand, per illustration.**

**When user steps on the platform, there should be no shifting or rocking of the Machine.**

